How to Strengthen Entry Security Without Replacing Every Door

Why Upgrading Existing Doors Often Makes Sense

Many homeowners assume that improving security means installing new doors throughout the house. That is rarely necessary. A solid door, even an older one, can be made significantly more secure with targeted upgrades to the locking hardware, strike plates, and frames. The key is understanding where vulnerabilities lie. Most break-ins exploit weak points in the lock or the door frame, not the door itself. By addressing those specific areas, you can raise the security level of every entry point without the expense and hassle of swapping out doors.

Step 1: Evaluate the Current Lock Grade and Cylinder Type

Start by checking what kind of lock is on each exterior door. Locks are graded by the American National Standards Institute (ANSI) on a scale from grade 1 (highest security) to grade 3 (basic residential use). Many stock doors come with grade 3 locks, which are fine for interior use but offer limited resistance to forced entry. If your locks are grade 2 or grade 3, consider upgrading to a grade 1 deadbolt or a multipoint lock system. A multipoint lock engages the door at several points along the frame, distributing force and making it far harder to kick in.

The cylinder is another critical component. Older pin tumbler cylinders are vulnerable to bumping and picking. Anti snap cylinders are designed to break away cleanly if snapped, preventing the lock from being turned. Replacing just the cylinder (rather than the entire lock) can be a quick, cost-effective improvement. When you move to professional residential lock upgrades, an experienced locksmith can advise on which cylinder type matches your existing door and lock body.

Step 2: Reinforce the Strike Plate and Door Frame

The strike plate is the metal piece attached to the door frame that the lock bolt slides into. Many standard strike plates are held in place by short screws that only penetrate the frame trim. Upgrading to a heavy-duty strike plate with long screws that reach into the wall's framing studs dramatically increases resistance to kick-in attacks. This is one of the simplest and most effective upgrades available. For wooden frames, the same principle applies: replace the standard strike plate with a reinforced version and use screws that are at least three inches long.

View the location on Google Maps

If the door frame itself is weak or rotted, you might need to reinforce it with a wrap-around plate or a frame reinforcement kit. These kits install over the existing frame and provide a metal backing for the strike plate and hinges. They are a good middle ground between a full door replacement and a basic strike plate swap. Always check that the new hardware matches the door material and that the holes align properly before committing to an installation.



Step 3: Upgrade to a High-Security Deadbolt

A deadbolt is a lock that cannot be pushed back into the door without turning the key or thumb turn. Single-cylinder deadbolts are standard, but double-cylinder versions offer added security because they require a key to lock or unlock from both sides. For doors with glass panels near the lock, a single-cylinder deadbolt can be vulnerable if the glass is broken and someone reaches inside to turn the thumb turn. A double-cylinder deadbolt eliminates that risk. Look for deadbolts with a hardened steel bolt and a reinforced strike plate. The bolt should extend at least one inch into the frame when locked.

Installing a deadbolt usually requires drilling a new hole in the door and frame. While a competent DIYer can do this, hiring a residential locksmith ensures the job is done precisely

and that the lock is properly aligned. A misaligned deadbolt can bind or fail to engage fully, which defeats its purpose. When considering professional residential lock upgrades, a locksmith can also recommend deadbolts that meet ANSI grade 1 standards and have anti pick pins in the cylinder.

Step 4: Implement Key Control and Rekeying

Key control is about managing who has access to your keys. If you have lost a key, moved into a new home, or handed out copies to contractors or babysitters, the security of your locks is compromised. Rekeying changes the internal pins of a lock so that old keys no longer work, while the lock hardware itself remains in place. This is far less expensive than replacing all locks. A locksmith can rekey multiple locks to operate with a single key, simplifying your key ring and reducing the chance of lost keys falling into the wrong hands.

Another option is to install a keyless entry system, such as a keypad lock or a smart lock. These systems allow you to change codes or revoke access remotely, giving you full control over who enters. However, they rely on batteries and digital components, so consider having a mechanical backup key override. A good practice is to use a keyless lock for convenience and a deadbolt for physical security.





Step 5: Address Secondary Entry Points

Side doors, garage entry doors, and sliding patio doors are often overlooked. A sliding door is vulnerable because its lock can be lifted or forced. A simple security bar placed in the track can prevent the door from sliding open. For hinged doors, follow the same steps as the front door: upgrade the strike plate, deadbolt, and cylinder. Garage service doors are a common target because they are less visible. Ensure they have a grade 2 or better lock and that the hinges are on the interior side or have non-removable pins.

Check the condition of the door frame and weatherstripping. Worn weatherstripping can make it easier to insert tools between the door and frame. Replace it when you upgrade the hardware. Also consider adding a door viewer or a wide-angle peephole to see who is outside before opening the door.

What to Watch Out For

One common mistake is upgrading the lock but ignoring the frame. A high-security deadbolt is only as strong as the frame it sits in. If the frame is soft wood or has been damaged by a previous break-in, reinforce it first. Another pitfall is installing a lock that does not fit the door cutout correctly, which can weaken the door structure. Always measure the backset (the distance from the edge of the door to the center of the lock hole) and the cross bore (the diameter of the hole for the lock body) before purchasing new hardware.

Beware of locks that claim to be pick-proof or bump-proof without certification. Look for locks that meet industry standards such as ANSI grade 1 or BHMA (Builders Hardware Manufacturers Association) ratings. Also, avoid locks with plastic components in the bolt or cylinder. Metal parts resist wear and forced entry better. Finally, do not rely solely on a single lock type. Layering security by using a deadbolt plus a keyed entry lock or a smart lock provides redundancy.



Okey Locksmith is also on YouTube.

Final Thoughts

Improving entry security without replacing every door is a practical approach that focuses time and money on the parts that matter most. By evaluating lock grades, reinforcing strike plates and frames, upgrading deadbolts, and taking control of keys, you can significantly lower the risk of a break-in. For professional assistance, consider reaching out to a local provider. Okey Locksmith provides 24/7 mobile automotive, residential, commercial, access control, and emergency locksmith services in Oklahoma City and nearby communities. They are located at 3121 SW 29th St, Oklahoma City, OK 73119, USA, and can be reached at +1 405-703-8943.